

IMPORTANT! Please read all instructions before installing.

Thank you for purchasing a Shakespeare antenna product. Shakespeare works hard to build reliability and durability into all of its products for maximum customer satisfaction.

The Classic 5101-S is an end-fed VHF marine antenna of 2.4m (8') overall length with matching stub and a stainless steel ferrule.

TOOLS REQUIRED:

- Soldering iron (40-watt min., 75 watt max.)
- Resin core solder
- Pocket knife
- Wire cutter

INSTALLATION INSTRUCTIONS

Choose a mounting location that is as high as possible, as free as possible from obstructions, and as far as possible from other antennas.

1. Mount the antenna using a Shakespeare 4187 Ratchet Mount (sold separately) or use a Shakespeare 4008 Extension Mast and a Shakespeare 410-R mounting kit (each sold separately) to form a 4.8m (16') antenna system. Follow the directions included with the mount you choose.
2. Route the cable to your radio, keeping it as far as possible from other electrical equipment and cables. Any excess cable should be rolled in a coil of at least 8" diameter and stowed in an out-of-the-way place, away from other electrical cabling. Install the PL-259 connector (supplied) according to the instructions packed with the connector.

This antenna requires no external or internal ground system, and works equally well on fiberglass, wood, or metal boats.

CLEANING INSTRUCTIONS

To clean the antenna, use mild dishwashing liquid (one that is not harsh to the hands and *without* ammonia) in lukewarm water.

WARNING: Do not let paint solvents, cleaning solvents or adhesive caulking come in contact with the antenna. Chemicals in these materials might destroy the finish.

SUPPLIED PARTS:

- 1 Antenna assembly
- 1 PL-259 connector with instruction sheet

TECH TIP: This antenna will read "open circuit" when tested with an ohm meter or continuity tester. The 50-ohm coaxial cable attached can be shortened as required. However, it should remain at least 0.9m (3') in length, measured from the point where the cable exits the antenna.

